Lab 2

Medical Imaging

IST 2021-2022

Consider the formation using a 1st generation scanner of a CT image of the modified Shepp-Logan phantom, which approximately models X-ray attenuation in a human head.

Note: for this lab you will need the scikit-image processing toolbox.

- 1. Generate the modified Shepp-Logan phantom using shepp_logan_phantom. Use the function rescale to get a 256x256 dimension.
- 2. Simulate the sinogram obtained by collecting projections covering [0;180[° in steps of 1° (using radon).
- 3. Simulate the associated reconstructed image using filtered backprojection (using iradon).
- 4. Repeat the simulations in 2. and 3. by covering: [0;60[°, [0;90[°, [0;120[° and [0;360[°, in steps of 1°.
- 5. Repeat the simulations in 2. and 3. by covering [0;180]°, in steps of 0.5, 5 and 10°.
 - 6. Repeat the simulations in 2. using the original angles, by adding noise to the projection data (using the random.poisson function of the numpy library), considering a maximum number of counts per pixel of 10³ photons. Note: as in this case noise follows the Poisson distribution, it depends on the signal level, so the output of the noise generation function will already correspond to the noisy sinogram. Prior to applying this function, you should rescale your sinogram intensities to the [0, 255] interval and convert the images to uint8 type (8-bit unsigned integers) to make the noise more noticeable.
- 7. Now reconstruct the image from the noisy projection data using iradon (with the original ramp, i.e. Ram-Lak, filter).
- 8. Repeat 7, by replacing the original Ram-Lak filter by modified filters (available in iradon), and explain the results as a function of their different frequency responses.